



Detachable PC Security Key Cable Lock

Model # NBL-S300


PACKAGE CONTENTS

- NBL-S300 Detachable PC Security Key Cable Lock
- Security Plate
- Velcro® Strap
- Alcohol Swipe
- Abrasive Pad
- Fastener Bracket
- Screws x 3


INSTALLATION INSTRUCTIONS

To Lock


1. Press the Release Button to detach the Lock Body from the Cable.




2. Anchor one end of the cable to a fixed object and pass the other end through objects to be fastened, such as PC, Fastener Bracket, etc.



3. Attach the Cable to the Lock Body, and you should hear the "Click" sound.



4. Circle the cable around the neck portion of the object, such as LCD monitor, and secure the cable in the Locking Slot.



5. Press down the Button and turn the key counterclockwise by 90° to lock.



To Unlock

Insert the key and turn clockwise by 90°. Pull out the Button and release the cable from the slot.






Detachable PC Security Key Cable lock

Model # NBL-S300

INSTALLATION INSTRUCTIONS

Anchoring

- 1 Circumvent the cable around a secured and fixed object. Take the Lock through the loop as shown. Use the VELCRO® strap to fasten the cable.
- 2 Using the Security Plate:
 - Use the Base Plate as a template to pre-drill the holes.
 - Smooth out the surface with abrasive pad if necessary
 - Apply the alcohol swipe to the area where the Security Base Plate will be attached.
 - Remove the adhesive strip and place the Base Plate to the prepared location and screw in both screws
 - Mount the plate cover back onto the plate to cover the screws.
 - Wrap your notebook lock cable around the ring to secure.



* Note: VELCRO® strap and all other trademarks are the property of their respective companies.

Warranty

The Detachable PC Security Key Cable Lock comes with a 1 year limited warranty. If your unit should become defective within that time frame, please go to <http://www.vantecusa.com> for information on how to receive warranty exchange or repair. Cosmetic defects and missing parts are not covered under this warranty. Please check the contents of the unit to make sure you received all parts. Also, check for any cosmetic flaws. If any parts are missing or if there are cosmetic defects, please contact the retailer from which you purchased the unit immediately and ask for a replacement.

Ordering replacement keys

To order replacement keys for your Detachable PC Security key Cable Lock, please contact Vantec Technical Support.

For your convenience, record the key serial number in the box.

Technical support/contact info

Vantec USA
43951 Boscell Rd
Fremont, CA94538

Email: support@vantecusa.com
Website: www.vantecusa.com